

Technician Checklist: Setting a Device IP via Laptop

1. Before You Begin

- ☐ Laptop with Ethernet port or adapter
- ☐ Ethernet cable
- ☐ OMNIA software installed
- ☐ Admin access on laptop
- ☐ Target network IP information available

2. Device Preparation

- ☐ Connect controller directly to laptop via Ethernet
- ☐ If IP is unknown, set dip switch 1 to ON
- ☐ Power cycle device
- ☐ Wait at least 45 seconds
- ☐ Set dip switch 1 back to OFF
- ☐ Confirm default IP is 192.168.100.1

3. Laptop Network Configuration

- ☐ Set laptop to static IP on 192.168.100.x subnet (not .1)
 - ☐ Subnet mask: 255.255.255.0
 - ☐ Gateway: 192.168.100.1
 - ☐ Confirm settings using ipconfig
- Discovery & IP Assignment
- ☐ Launch OMNIA Discovery Tool
 - ☐ Scan subnet or search by IP (192.168.100.1)
 - ☐ Open device network settings
 - ☐ Select Static IP
 - ☐ Enter final IP, subnet mask, and gateway
 - ☐ Password used: masterkey
 - ☐ Save and confirm successful update

Final Verification

- ☐ Disconnect direct laptop connection
- ☐ Install device on live network
- ☐ Verify device is reachable on assigned IP
- ☐ Confirm communication with host system